Spa Water Care Products - A Quick Guide

The information below is a quick guide for the products you will need to maintain Safe, Clean, Sparkling water in your spa.



Product Name:	What this product does and how much to add	How Often
InstaTest 4+ Test Strips	Gives values for the chemical balance of your spa water	Before Use
Dip in the spa water	for 2 seconds, remove facing upwards, shake excess water off and re	ead immediately.
Bromine Granules	Sanitises water, kills bacteria & fungus	Always
Add 2gms per 1,000Lts of spa water to raise Bromine level by 1ppm - ALWAYS check Bromine ppm prior to use.		
Non-Chlorine Shock	Helps keep water clear & revives Bromine	Weekly
Add 11gms pe	er 1,000 Lts of spa water after bathing and run pumps for 30 mins wi	ith the cover off.
Instant Filter Cleaner	For quick cleaning filters - Removes oil & grease	Weekly
	Spray onto the filter, leave for 15 minutes, then rinse thoroughly v	with a hose pipe.
Spa Rapid Shock	Very fast acting sanitiser and oxidiser	Monthly
Add 15gms per 1	,000 Lts of spa water - DO NOT use spa until Chlorine/Bromine leve	l is below 5ppm.
IMMERSE Filter Cleaner	For deep cleaning filters - Removes oil, grease & minerals	Monthly
Dissolve in a container of	of water large enough to hold your filter, leave overnight, remove & r	rinse thoroughly.
pH MINUS	Reduces the pH - Use when the pH reading is above 7.6	As Needed
Add 11gms per 1,000 L	ts of spa water for 0.2 DECREASE - check readings after 30 mins befo	ore adding more.
TA Plus	Increases the Total Alkalinity - Use when TA is below 70 ppm	As Needed
Add 18gms per 1,000 Lts of spa water for 10 ppm INCREASE - check readings after 30 mins before adding more.		
pH PLUS	Increases the pH - Use when the pH reading is below 7.2	As Needed
Add 11gms per 1,000 L	ts of spa water for 0.2 INCREASE - check readings after 30 mins befo	ore adding more.
Spa Surface Cleaner	Cleans the spa surface and waterline	As Needed
Use with a sponge or cloth to remove waterline oil & grease and to clean the spa shell at the water change.		
Hot Tub Flush	Cleans the Spa plumbing at water changes	3 Monthly
	Cleans the Spa plumbing at water changes e spa water, run pumps for 30 mins, leave overnight, run pumps 40 mins, run pumps 40 mins	•
		•
Add 250ml to th	e spa water, run pumps for 30 mins, leave overnight, run pumps 30 i	mins, then drain. 3 Monthly
Add 250ml to th	le spa water, run pumps for 30 mins, leave overnight, run pumps 30 Increases the Calcium Hardness of water to prevent corrosion	mins, then drain. 3 Monthly
Add 250ml to the Hardness PLUS Use when refilling the spa Spa Cover 303 Protectant	le spa water, run pumps for 30 mins, leave overnight, run pumps 40	3 Monthly dness by 25ppm. 3 Monthly
Add 250ml to the Hardness PLUS Use when refilling the spa Spa Cover 303 Protectant Wash off excess dirt w	Increases the Calcium Hardness of water to prevent corrosion with fresh soft water - Add 38gms per 1,000 Lts to increase the Hardness the Spa Cover from U.V. damage	mins, then drain. 3 Monthly dness by 25ppm. 3 Monthly a clean dry cloth.
Add 250ml to the Hardness PLUS Use when refilling the spa Spa Cover 303 Protectant Wash off excess dirt w Optional Spa Cover Spa FoamAway	Increases the Calcium Hardness of water to prevent corrosion with fresh soft water - Add 38gms per 1,000 Lts to increase the Hardness the Spa Cover from U.V. damage ith soapy water & dry - Spray the 303 onto the cover then buff with a Care products to combat special conditions or assist with water care Reduces foam on the spa water surface	3 Monthly dness by 25ppm. 3 Monthly clean dry cloth. As Needed
Add 250ml to the Hardness PLUS Use when refilling the spa Spa Cover 303 Protectant Wash off excess dirt w Optional Spa Cover Spa FoamAway	Increases the Calcium Hardness of water to prevent corrosion with fresh soft water - Add 38gms per 1,000 Lts to increase the Hardness the Spa Cover from U.V. damage ith soapy water & dry - Spray the 303 onto the cover then buff with a Care products to combat special conditions or assist with water care	3 Monthly dness by 25ppm. 3 Monthly clean dry cloth. As Needed
Add 250ml to the Hardness PLUS Use when refilling the spa Spa Cover 303 Protectant Wash off excess dirt w Optional Spa C Spa FoamAway Per Spa ScaleAway	Increases the Calcium Hardness of water to prevent corrosion with fresh soft water - Add 38gms per 1,000 Lts to increase the Hardness the Spa Cover from U.V. damage ith soapy water & dry - Spray the 303 onto the cover then buff with a Care products to combat special conditions or assist with water care Reduces foam on the spa water surface 1,000 Lts of spa water add 100ml initially, then 50ml per week if products Calcium and other minerals out of the water	3 Monthly dness by 25ppm. 3 Monthly a clean dry cloth. As Needed oblem continues. As Needed
Add 250ml to the Hardness PLUS Use when refilling the spa Spa Cover 303 Protectant Wash off excess dirt w Optional Spa C Spa FoamAway Per Spa ScaleAway	Increases the Calcium Hardness of water to prevent corrosion with fresh soft water - Add 38gms per 1,000 Lts to increase the Hardness the Spa Cover from U.V. damage ith soapy water & dry - Spray the 303 onto the cover then buff with a Care products to combat special conditions or assist with water care Reduces foam on the spa water surface 1,000 Lts of spa water add 100ml initially, then 50ml per week if products of spa water add 100ml initially, then 50ml per week if products of spa water add 100ml initially, then 50ml per week if products of spa water add 100ml initially, then 50ml per week if products to combat space and 100ml initially, then 50ml per week if products to combat space and 100ml initially, then 50ml per week if products to combat space and 100ml initially, then 50ml per week if products to combat space and 100ml initially, then 50ml per week if products to combat space and 100ml initially, then 50ml per week if products to combat space and 100ml initially, then 50ml per week if products to combat space and 100ml initially, then 50ml per week if products to combat space and 100ml initially, then 50ml per week if products to combat space and 100ml initially, then 50ml per week if products to combat space and 100ml initially, then 50ml per week if products to combat space and 100ml initially then 50ml per week if products to combat space and 100ml initially then 50ml per week if products to combat space and 100ml initially then 50ml per week if products to combat space and 100ml initially then 50ml per week if products to combat space and 100ml initially then 50ml per week if products to combat space and 100ml initially then 50ml per week if products the 100ml p	3 Monthly dness by 25ppm. 3 Monthly a clean dry cloth. As Needed oblem continues. As Needed
Add 250ml to the Hardness PLUS Use when refilling the spa Spa Cover 303 Protectant Wash off excess dirt w Optional Spa C Spa FoamAway Per Spa ScaleAway	Increases the Calcium Hardness of water to prevent corrosion with fresh soft water - Add 38gms per 1,000 Lts to increase the Hardness the Spa Cover from U.V. damage ith soapy water & dry - Spray the 303 onto the cover then buff with a Care products to combat special conditions or assist with water care Reduces foam on the spa water surface 1,000 Lts of spa water add 100ml initially, then 50ml per week if products Calcium and other minerals out of the water	3 Monthly dness by 25ppm. 3 Monthly a clean dry cloth. As Needed oblem continues. As Needed
Add 250ml to the Hardness PLUS Use when refilling the spa Spa Cover 303 Protectant Wash off excess dirt w Optional Spa C Spa FoamAway Per Spa ScaleAway Use when Total hardness Oil Absorber - Zorbo	Increases the Calcium Hardness of water to prevent corrosion with fresh soft water - Add 38gms per 1,000 Lts to increase the Hardness the Spa Cover from U.V. damage ith soapy water & dry - Spray the 303 onto the cover then buff with a Care products to combat special conditions or assist with water care Reduces foam on the spa water surface 1,000 Lts of spa water add 100ml initially, then 50ml per week if products Calcium and other minerals out of the water is above 200ppm - For 1,000 Lts of spa water add 25ml initially, then	a Monthly dness by 25ppm. 3 Monthly dness by 25ppm. 3 Monthly d clean dry cloth. As Needed beloblem continues. As Needed 15ml per week. Always
Add 250ml to the Hardness PLUS Use when refilling the space Spa Cover 303 Protectant Wash off excess dirt w Optional Spa C Spa FoamAway Per Spa ScaleAway Use when Total hardness Oil Absorber - Zorbo Rinse Spa Perfect	Increases the Calcium Hardness of water to prevent corrosion with fresh soft water - Add 38gms per 1,000 Lts to increase the Hardness the Spa Cover from U.V. damage ith soapy water & dry - Spray the 303 onto the cover then buff with a Care products to combat special conditions or assist with water care Reduces foam on the spa water surface 1,000 Lts of spa water add 100ml initially, then 50ml per week if products above 200ppm - For 1,000 Lts of spa water add 25ml initially, then Absorbs Oils & Lotions from the spa water eclean every week with fresh water DO NOT use detergent, replace Reduces chemical demand, waterline ring & softens the water	a clean dry cloth. As Needed blem continues. Weekly
Add 250ml to the Hardness PLUS Use when refilling the space Spa Cover 303 Protectant Wash off excess dirt w Optional Spa C Spa FoamAway Per Spa ScaleAway Use when Total hardness Oil Absorber - Zorbo Rinse Spa Perfect	Increases the Calcium Hardness of water to prevent corrosion with fresh soft water - Add 38gms per 1,000 Lts to increase the Hardness the Spa Cover from U.V. damage ith soapy water & dry - Spray the 303 onto the cover then buff with a Care products to combat special conditions or assist with water care Reduces foam on the spa water surface 1,000 Lts of spa water add 100ml initially, then 50ml per week if products Calcium and other minerals out of the water is above 200ppm - For 1,000 Lts of spa water add 25ml initially, then Absorbs Oils & Lotions from the spa water	a clean dry cloth. As Needed blem continues. Weekly
Add 250ml to the Hardness PLUS Use when refilling the space Spa Cover 303 Protectant Wash off excess dirt w Optional Spa C Spa FoamAway Per Spa ScaleAway Use when Total hardness Oil Absorber - Zorbo Rinse Spa Perfect	Increases the Calcium Hardness of water to prevent corrosion with fresh soft water - Add 38gms per 1,000 Lts to increase the Hardness the Spa Cover from U.V. damage ith soapy water & dry - Spray the 303 onto the cover then buff with a Care products to combat special conditions or assist with water care Reduces foam on the spa water surface 1,000 Lts of spa water add 100ml initially, then 50ml per week if products above 200ppm - For 1,000 Lts of spa water add 25ml initially, then Absorbs Oils & Lotions from the spa water eclean every week with fresh water DO NOT use detergent, replace Reduces chemical demand, waterline ring & softens the water	a clean dry cloth. As Needed blem continues. Weekly